

Cedar County Engineer 400 Cedar Street Tipton, IA 52772

Phone 563-886-6102 engineer@cedarcounty.iowa.gov

# ROUND TRIP PERMIT APPLICATION

Section A -	ssued	to: Pleas	e print	clearly o	r type.			Permit	Fee - \$70			
Check/Cash Escrow Account							Requested Start Date					
Legal Name - Vehicle Owner or Lessee							Phone Number			U.S. DOT Number		
Address							FAX Number			MC Number		
City State ZIP Code							Carrier Type			Iowa Intrastate Authority Number		
							For Hire Private			Towa mirastate Authority Number		
Email Address	3					Conta	ct Name fo	or DOT to call if ques	stions / Area	Code - Telephone No.		
Section B - Load - Describe Article(s) Transported										Model Number		
						SWE (	SME Qualified? Yes No			Serial Number		
Section C -		-   4 O T	-11 1 6		-	SIVIE	qualified?	☐ Yes ☐ No				
Power Unit -	Both P	late/State	and VIN	ormation I must be	n. e identified.							
Plate	State				tion Number (VIN)	)	Registered Weight			Make		
Trailer - Plate		must be i	dentified									
Plate State Make					Make		Other (provide details)					
Section D -	Dimens	sions/We	ight									
Length		Overall		Trailer		Lo	Load Front Pro		ection	Rear Projection		
Width						August N	ACT OF STREET		Tark A. Carlos	AND THE RESIDENCE SHARING THE CONTRACTOR		
Height				Carlo Sept. 1881 Sept. Staff of Carlo Sept. 2019 Carlo Se						A CONTROL OF THE CONT		
Gross Weight										CONTRACTOR STATEMENT		
		eights/Sr	acinas	- front to	rear (required w	hen gross	voight ov	randa 80 000 lb-	•			
Axle Number Gross Axle Weight (lbs)	le			2	3		4	5	6	7		
Axle Spacing				T								
Axle Number Gross Axle Weight (lbs)		8		9	10		11	12	13	14		
Axle Spacing									T			
Section F -	rip			•				<del></del>				
Coming From							Going To					
Route								<u></u>				
Section G -	Permit	delivery	(check	one)								
Name			•			Approve	d:					
Mailing Ad	dress					Acce in the	otance o applicat	f Conditions: I ce	ertify that th	ne statements contained d I will comply with the		
FAX			Ema			Gene	ral Provis	ions dated 06-200	08.			
					2 100	X						
							(Custo	mer or Authorized A	(gent)	Date		



#### IOWA GENERAL PROVISIONS FOR OVERSIZE LOAD PERMIT

The State of lowa, the lowa Department of Transportation, and any other permit issuing authority assume no responsibility for the property of the permit holder. During movement under permit, the permit holder must meet the terms and conditions of the permit and must take all reasonable precautions to protect and safeguard the lives and property of the traveling public and adjacent property owners. A copy of a current certificate of public liability insurance in the amounts of \$100,000 bodily injury each person, \$200,000 bodily injury each occurrence, and \$50,000 property damage must be carried in the vehicle for which the permit has been issued. Nothing shall exempt the permit holder from compliance with any load limitations that have been or might be established on any bridge or road posted with embargo signs. The permit and any revisions will be void if the actual weights or dimensions exceed what is indicated on the permit or its revisions. Permits can be issued only for loads that are a single article that cannot be reasonably broken down to make it legal in size and weight. The permit must be carried in the cab of the vehicle for which it has been issued and be available for inspection. Proof of liability insurance may be either in writing or in electronic format.

Movement is allowed seven days a week except for designated holidays and for special events when abnormally high traffic counts can be expected. The designated holidays are Memorial Day, Independence Day, and Labor Day. No movement will be allowed on these holidays or after 12 noon on days preceding these holidays and holiday weekends that include holidays falling on Monday, except as provided for in Iowa Code 321.457.

Annual permits: Routes must be checked for construction restrictions and clearance problems using the vertical clearance maps, bridge embargo maps, pavement restriction maps, and the 511ia.org website prior to moving under permit. Maps can be found at lowadot.gov/mvd/motorcarriers.

Escort requirements: Escorts must be at least 18 years old, possess a valid Class A, B, C, or D driver's license, and carry proof of public liability insurance in the amounts of \$100,000/\$200,000/\$50,000. The escort vehicle must be approximately the size of a normal passenger automobile or pickup and must have a flashing or strobe amber light that shall be burning while escorting a permit load. The escorting vehicle shall not be used to tow a trailer while performing escorting duties. The escort shall not assume responsibility for stopping traffic. An on-duty peace officer, as defined in Iowa Code section 321.1, shall be contacted to provide any traffic control needed.

#### Required warning devices and escort requirements for vehicles operating under permit

	Flags/Signs	Lights	Escorts		
			Four-lane	Two-lane	
Length					
75'1" up to and including 85'	Yes	Not required	Not required	Not required	
Over 85' up to and including 120'	Yes	Yes	Not required	Not required	
Over 120'	Yes	Not required	Rear	Rear	
Projections					
Front: over 25'	Not required	Yes	Not required	Not required	
Rear: over 4' up to and including 10'	Flags only	Not required	Not required	Not required	
Rear: over 10'	Flags only	Yes	Not required	Not required	
Height					
Over 14'6" up to 20'	Yes	Not required	Front with a height pole	Front with a height pole	
Weight					
Over 80,000 lbs.	Not required	No	Not required	Not required	
Width					
Over 8'6" up to 12'	Yes	Not required	Not required	Not required	
Over 12' up to and including 14'6"	Yes	Not required	Rear*	Front*	
Over 14'6" up to and including 16'6"	Yes	Not required	Rear*	Front	
Over 16'6" up to and including 18'	Yes.	Not required	Rear	Front	

<sup>\*</sup>In lieu of an escort, a vehicle can display an amber light or strobe on the power unit and on the rear extremity of the load.

Lighting requirements: A flashing or strobe amber light that is visible for at least 500 feet and provides 360-degree warning, mounted on the towing unit is required. An escort can be used in lieu of amber light.

Signs and flags: A sign reading "Oversize Load" must be at least 18 inches high by 7 feet long with a minimum of 10-inch black letters with a 1 1/2-inch stroke, on a yellow background, and mounted on the front bumper and on the rear of the load. A rear sign for mobile homes must be mounted at least 7 feet above the highway surface, measuring from the bottom of the sign. Flags must be red or orange fluorescent and at least 18 inches square. Flags must be mounted as follows: one flag at each front corner of the towing unit and one flag at each rear corner of the load. In addition, there must be a flag at any additional protrusion in the width of the load. The signs or warning devices must be mounted so they can be removed or covered when the vehicle is within legal dimensions.

Permitted tandem axle weights: Vehicles operating under a permit issued pursuant to Iowa Code 321E.9, or 321E.9A may have a gross weight not to exceed 46,000 pounds on a single-tandem axle of the truck tractor and a gross weight not to exceed 46,000 pounds on a single-tandem axle of the trailer or semitrailer if each axle of each tandem group has at least four tires. No single axle of the tandem group may exceed 24,000 pounds. If the tandem axle is within a larger group of axles, the maximum weight of that specific group of axles shall not exceed 20,000 pounds per axle.

Requirements for continuous moves: Vehicles and loads may travel by permit between 1/2 hour after sunset and 1/2 hour before sunrise if, in addition to the general provisions and general requirements specified by the permit, the following conditions are met.

- a. Dimensions shall not exceed:
  - (1) Width: 11 feet.
  - (2) Height: 14 feet, 6 inches.
  - (3) Length: 100 feet.
  - (4) Weight: Permitted axle limits.
- b. Travel must be on roadways with a minimum width of 22 feet and minimum lane width of 11 feet.
- c. Safety lighting shall be provided at the widest part of a load. The lamps may be placed at the outer ends of the load itself or on appurtenances that are equal in width to the widest part of the load and positioned at both extreme front and rear of the vehicle or trailer as follows.
  - (1) One lighted red lamp on each side at the rear of the load.
  - (2) One lighted yellow or amber lamp on each side at the front of the load.



# INSTRUCTIONS FOR COMPLETING A ROUND TRIP OVERDIMENSION AND/OR OVERWEIGHT PERMIT APPLICATION

#### Section A

Charge Account/Escrow Account/Credit card: Check the box next to your desired method of payment and then enter the corresponding number in the space.

Email address: Enter your email contact information.

Requested Start Date: Enter the date you would like the permit to start. Permits are good for five days.

Legal Name: Enter the name of the person or company that the permit will be issued to.

Phone Number: Enter the contact phone number.

MC Number: Enter your MC number if you are a for hire carrier with Interstate authority.

Intrastate Authority: Enter your lowa Intrastate authority number

Carrier Type: Check one box. Are you hauling this load for hire or privately?

Address/City/State/ZIP: Enter the address of the person or company that the permit will be issued to.

Fax Number: Enter the contact fax number.

**US DOT Number:** Enter your USDOT number here. If no USDOT number is required for your operation, enter NA. To determine if you are required to have a USDOT number, visit the web site www.safersys.org

Contact Name: Enter the name of the person to be contacted with questions regarding this application. Also enter a phone number if different than the one already on the application

#### Section B - Load information

Load: Enter the description of your load, i.e., excavator, farm tractor, wind tower, self-propelled crane, etc.

Carrier Type: Check one box. Are you hauling this load for hire or privately?

Model Number: Enter the model number. If the load is steel beams, trusses, etc, a model number is not required.

SME Qualified: Enter "Yes" if your load qualifies as 'Special Mobile Equipment' If not, enter No.

Serial Number: Enter the serial number. If the load is steel beams, trusses, etc, a serial number is not required.

# Section C - Power Unit & Trailer information

Plate: Enter the license plate number for the power unit.

State: Enter the 2 digit abbreviation for the state the power unit is registered in.

Vehicle Identification Number (VIN): Enter the VIN for the power unit.

Registered Weight: Enter the registered weight of the power unit. This information can be found on your cab card. Iowa law requires that you be registered for the weight you are hauling. Please include a copy of your cab card with the application.

Year: Enter the year of the power unit.

Make: Enter the make of the power unit (Peterbilt, Mack, International, etc)

# Section C - Power Unit & Trailer information

Trailer information: Enter the plate number, state, and make for each trailer on a separate line.

Other: Enter any miscellaneous comments about the trailer or vehicle configuration here

# Section D - Dimensions/Weight

Overall Length: Measure from the front bumper of the power unit to the end of the trailer or load. Enter in feet and inches.

Overall Width: Enter in feet and inches.

Overall Height: Tallest point, either power unit or load. Enter in feet and inches.

Trailer and load length: Measure from the front of the trailer or load, to the end of the trailer or load. Enter in feet and inches.

Front Projection: Any overhang that extends past the front of the power unit. Enter in feet.

Rear Projection: Any overhang that extends past the rear of the power unit; or trailer if a combination vehicle. Enter in feet.

Overall Gross Weight: Total weight of power unit, trailer, and load combined. Enter in pounds.

# Section E - Axle weight/spacing

If over 80,000 lbs. or special mobile equipment with qualifying tires, enter individual axle weights and spacings. If under 80,000 lbs., skip to Section F.

Requested Gross Axle Weight: Enter weight for each axle in pounds.

Spacing Between Axles: Enter each individual axle spacing in feet and inches.

# Section F - Trip Information

Coming from: Enter the city, Interstate exit number, address, or location where the trip begins. If the total weight of the load is over 156,000 lbs. and the trip does not start or end in Iowa, also include the original origin of the load.

Going to: Enter the city, Interstate exit number, address, or location where the trip ends. If the total weight of the load is over 156,000 lbs. and the trip does not start or end in lowa, also include the final destination of the load.

Route: Enter your desired route, separated by commas. (i.e. Nebraska line, I-80, US-59, etc.)

#### Section G - Permit delivery

Check the appropriate box telling us how you would like your permit delivered to you once it has been issued. Choose Mail, Fax, or email, and fill in the corresponding information.

Acceptance of conditions: Sign on the line to certify that you have read the "lowa General Provisions for Oversize Load Permit" – your signature acknowledges that you have read and will comply with them.